




TOP AND CABINET PARTS

For Models: LSQ9200PQ4, LSQ9200PT4
(Designer White) (Biscuit)

AUTOMATIC
WASHER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CABINET PARTS

For Models: LSQ9200PQ4, LSQ9200PT4
(Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	3958075	Installation Instructions
	3955907	Feature Sheet
	8578232	Use & Care Guide
	3957474	Energy Guide
	8557303	Wiring Diagram


Following May Be Purchased

DO-IT-YOURSELF REPAIR MANUALS

	4313896	Manual, Washer Do-It-Yourself
2		Top
	8318064	White
	8318066	Biscuit
3	62750	Spacer, Cabinet To Top (4)
4	357213	Nut, Push-In (2)
5		Cabinet
	63424	White
	3954357	Biscuit
6	62780	Clip, Top & Cabinet & Rear Panel (2)
7	3362952	Dispenser, Bleach
8	3351614	Screw, Ground
9	3357011	Screw, 10-16 x 1/2
11	8318084	Switch, Lid
13	3351355	Screw, Lid Hinge Mounting (4)
15	8318088	Hinge, Lid (L.H.)
16	54583	Hinge, Lid (R.H.)
17	19119	Bumper, Lid Hinge
18	21258	Bearing, Lid Hinge (2)
19		Lid
	8542387	White
	8542384	Biscuit
20	3976348	Cabinet- Sound Damper
21	9724509	Bumper, Lid (2)
22	3390631	Screw, 10-16 x 3/8 (4)

CONTROLS AND REAR PANEL PARTS

For Models: LSQ9200PQ4, LSQ9200PT4
(Designer White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROLS AND REAR PANEL PARTS

For Models: LSQ9200PQ4, LSQ9200PT4

(Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3976300	Washer, Water Inlet Hose (4) (1-1/16 x 5/8)	22	8541607	Hose, Vacuum Break	45		Dial, Timer
2	3400073	Screw, Ground	23	370450	Clamp, Hose		8544947	White
3		Hose, Water Inlet (2)	24	387606	Break, Vacuum	46	8544948	Biscuit
	8571377	Blue Coupler	25	303294	Edge Protector	47	8536939	Clip, Knob
	8571378	Red Coupler	26	8572717	Capacitor, Motor Start		8544935	White
4	9740848	Screw, 8-18 x 1/2	27	8541667	Clamp, Hose		8544936	Biscuit
5	8568314	Strap, Console (2)	28	8541668	Clamp, Hose	49	388326	Screw, 8-18 x 1.25 (Panel to Top)
6	8318015	Panel, Rear	30	3363366	Clamp, Hose	50	62863	Screw, 10-16 x 3/8
7	62747	Pad, Rear Panel	31	8317496	Clamp, Hose	51		Cap, End (R.H.)
8	8559373	Drain Hose Assembly (Includes Items 27 & 28)	32	3951449	Hose, Pump To Tub (Includes Item 30)		8271359	White
9	8557301	Timer, Control (60 Hz.) (Motor Not A Service Part)	33	8055003	Clip, Harness & Pressure Hose		8271362	Biscuit
10	3351614	Screw, Ground	34	8317975	Retainer, Harness	52	8541672	U-Bend, Drain Hose
11	90767	Screw 8-18 x 3/8	35	661612	Switch, Water Temperature	53	8539874	Shield, Suds
12	3366847	Switch, Water Level	36	3400818	Screw, Timer Mounting	54	3957023	Harness, Wiring (For Detail See Pages 9 & 10)
13	3948608	Bracket, Control	37	3949180	Switch, Rotary	55	3347868	Cable Tie
14	661661	Cord, Power (Includes Item 15)	38	3949187	Switch, Rotary	56	8519200	Support, Rear Panel
15	8559349	Strain Relief, Power Cord	39		Panel, Console			
16		Cap, End (L.H.)		3956580	White			
	8271365	White		3956581	Biscuit			
	8271368	Biscuit	41	8541669	Bucket, Drain Hose (Left Half)			
17	8318046	Clip, Capacitor	42	8541658	Bucket, Drain Hose (Right Half)			
18	3952164	Valve, Water Mixing			Knob, Timer			
20	694419	Mini-Buzzer	44					
21	301958	Clamp, Hose		8544943	White			
				8544944	Biscuit			

FOLLOWING PARTS NOT ILLUSTRATED


3957361 Miscellaneous Parts Bag

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

AGITATOR, BASKET AND TUB PARTS

For Models: LSQ9200PQ4, LSQ9200PT4

(Designer White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

AGITATOR, BASKET AND TUB PARTS

For Models: LSQ9200PQ4, LSQ9200PT4
(Designer White) (Biscuit)


Illus. No.	Part No.	DESCRIPTION
1	63580	Dispenser
2	358237	Screw & Washer (5/16-24 x 1)
3	3348752	Clothes Mover
4	3347288	Agitator
5	8528150	Tub Ring & Gasket
6	3976308	Gasket, Tub Ring
7	3354845	Clip, Agitator
8	8543666	Washer, Agitator
9	3363663	Cam Driven
10	3366877	Dog, Agitator Clutch (4)
11	3363661	Bearing-Driven Cam
12	21366	Nut, Spanner
13	8526016	Basket & Balance Ring
14	2219077	Clip, Pressure Switch Hose
15	8519788	Balance Ring
16	63849	Tub
17	389140	Block, Basket Drive
18	383727	Gasket, Centerpost
19	3347780	Hose, Pressure Switch
20	3348117	Agitator (Complete)
22	3350389	Spacer, Thrust
23	3354733	Cap, Barrier
24	3348855	Seal, Inner Cap
26	3949550	Washer

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MACHINE BASE PARTS

For Models: LSQ9200PQ4, LSQ9200PT4


(Designer White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


BRAKE, CLUTCH, GEARCASE, MOTOR AND PUMP PARTS

For Models: LSQ9200PQ4, LSQ9200PT4
(Designer White) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1	388952	Brake & Drive Tube (Complete) (Refer to Page 11 For Further Breakdown)
2	63292	Washer, Spin Tube Thrust
3	62697	Ring, Spin Tube Support
4	63283	Ring, Retainer
5	3951311	Clutch (Complete)
6	3951308	Band & Lining, Clutch (Includes Items 7 & 8)
7	62646	Cap, Clutch Spring (2)
8	3946792	Spring, Clutch
9	3360630	Gearcase (Complete) (Refer To Page 12 For Further Breakdown)


Illus. No.	Part No.	DESCRIPTION
10	3357334	Screw, Gearcase To Base (3)
11	62611	Plate, Motor Mount To Gearcase
12	62691	Grommet, Motor (4)
13	285753	Coupling, Motor & Isolation
14	8577374	Seal
15	3355454	Clip, Anti-Rattle
16	3400516	Screw
17	3349637	Retainer, Motor (2)
18	3362089	Shield, Tub To Motor
19	8528157	Motor, Main Drive
20	3952056	Switch, Main Drive Motor
21	8546127	Retainer, Pump (2)
22	3363394	Pump (Complete)
23	3387485	Screw, 10-16 x 5/8
24	3946532	Shield, Motor



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WIRING HARNESS PARTS

For Models: LSQ9200PQ4, LSQ9200PT4
(Designer White) (Biscuit)



WH2I

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WIRING HARNESS PARTS

For Models: LSQ9200PQ4, LSQ9200PT4

(Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3349557	Clip, Harness	10	353424	Plug, Terminal (3-Way) (Power Cord) (Use Term.94613)	17	3347730	Receptacle (6-Way) (Use Term. 94613)
2	388498	Clip, Harness				18	3349494	Connector, Etc
3	3347812	Clip, Harness	11	62505	Block, Disconnect (Motor 2 Speed) (Use Term.352088)	19	3407125	E.T.C. Control
4	3352501	Clip, Harness	12	3347243	Block, Disconnect (Use Term. 352088)	20	3948617	Connector (T.P.A.) (3-Circuit) (Lid Switch)
5	90016	Clip, Harness	13	63523	Protector	21	3360056	Connector (T.P.A.) (3-Circuit) (Pressure Switch)
6	3390496	Clip, Harness	14	717252	Connector (2-Way) (Use Term.94614)	22		Block, Connector
7	389379	Retainer, (Suds Models) Timer, Block Disconnect	15	3352944	Clip, Harness		3354925	Cold Valve
8			16	3390423	Block, Disconnect (12-Way) (Timer) (Use Term. 94613)		3354926	Hot Valve
	3948614	White						
	352089	Black						
9	62889	Receptacle, Terminal (3-Way) (Lid Switch) (Use Term.94613) Or 94614.)						

**FOR COMPLETE WIRING HARNESS REFER TO
CONTROL AND REAR PANEL PARTS PAGE**


WH2I

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BRAKE AND DRIVE TUBE PARTS

For Models: LSQ9200PQ4, LSQ9200PT4

(Designer White) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1	388952	Brake And Drive Tube (Complete)
2	62658	Ring, Thrust
3	356427	Seal, Drive Tube
4	64027	Tube, Basket Drive (Includes Illus. 3, 4, 5 & 9)
5	64035	Ring, Retaining
6	64232	Shoe, Brake (2)
7	62703	"T" Bearing, Spin Tube
8	3353956	Cap, Brake Spring (2)
9	387806	Spring, Brake
10	3355360	Sleeve, Brake Spring
11	661516	Cam, Brake Release
12	63022	Sleeve, Cam
13	64194	Driver, Brake Cam
14	90368	Ring, Retaining

FOLLOWING PARTS NOT ILLUSTRATED

285208 Lubricant
(Use Only In Brake Shoe Assembly On Roller & Pin)


BD-315-B

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

GEARCASE PARTS

For Models: LSQ9200PQ4, LSQ9200PT4

(Designer White) (Biscuit)






Illus. No.	Part No.	DESCRIPTION
1	3360630	Gearcase (Complete)
2	285202	Cover, Gearcase
3	3349985	Seal, Gearcase Cover
4	285195	Sealer, Gasket (.20 Fl. Oz.) (6 ml)
5	63320	Pinion, Spin (Includes Illus. 25)
6	356427	Seal, Spin Pinion
7	389387	Shaft, Agitator (Complete)
8	90369	Ring, Retaining (2)
9	62677	Retainer, Spring
10	62676	Spring, Agitate
11	63273	Gear, Agitate (Includes 15 and 29)
12	62619	Washer, Agitate Gear
13	62580	Cam Follower (Includes 14)
14	62581	Cam, Agitate (Includes 13)
15	285509	Shaft, Agitator (Includes 11 and 29)
16	62618	Washer, Cam Thrust
17	16018	Bearing, Thrust
18	85529	Ball, Bearing
19	389230	Bottom and Pinion, Gearcase
21	285352	Seal, Thrust Plug
22	3351614	Screw, Gearcase Cover, Mounting (8) (10-24 x 3/8)
23	3362552	Ring, Retaining
24	285735	Washer Kit, Thrust
25	62570	Gear, Spin
26	388253	Neutral Assembly
27	3349296	Rack, Connecting Actuator, Shift
28	62621	Washer, Intermediate
29	388815	Washer, Intermediate

GC-215-C

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WATER SYSTEM PARTS

For Models: LSQ9200PQ4, LSQ9200PT4
(Designer White) (Biscuit)



WS400

Illus. No.	Part No.	DESCRIPTION
1	285442	Connector Kit, Plastic Drain Hose
2	285321	Sleeve Kit, (Contains 2 Sleeves)
3	370447	Clamp, Hose
4	16272	Connector, Straight
5	285320	Siphon Break Kit (Not Included)
6	65349	Clamp, Hose
7	367031	Drain Protector (Not Included)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Models: LSQ9200PQ4, LSQ9200PT4
(Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
---------------	-------------	-------------

PAINT, TOUCH-UP (1/2oz.)

72017 White
4392899 Biscuit

PAINT, PRESSURIZED SPRAY (12 oz.)

350938 Primer, Gray
350930 White
4392901 Biscuit

PAINT, BULK (1 qt.)

799344 White (Uncut)
4392900 Biscuit (Uncut)

OIL

350572 Oil, Gearcase
(16 Oz.)

LUBRICANT

285208 Lubricant (Use
Only in Brake
Shoe Assembly
On Roller and
Pin)

SEALER

285195 Sealer, Gasket
(.20 Fl. Oz.) (6 ml)

ACCESSORY PARTS

367031 Drain Protector
285320 Siphon Break Kit